



- I. "A" and "B" reset Interlock boxes #1 and #2.
- II. "A" and "B" check the 4 doors that should be locked with a RSO lock.
- III. "A" holds while "B" checks behind the equipment, resets Interlock box #3, sweeps the spur and resets Interlock box #4, and then joins "A."
- IV. "A" holds while "B" checks the D0 MVA and resets Interlock box #5.
- V. "A" holds while "B" resets Interlock box #9. Also, "B" checks the grating to make sure it's still locked.
- VI. After "B" signals "A" that Interlock box #9 is reset, "A" checks the stairwell and resets Interlock box #10. "A" joins "B" and they control access into B-Sector to continue the search and secure.

Hold¹- "B" waits while "A" checks the stairwell and resets the Interlock box at the service building.